

Troubleshooting an Apple laptop display that is flickering or frequently going black.

Erich S. Lehman - 2024-09-01 - Troubleshooting Guides

If you encounter a problem where your Apple laptop screen flickers or blacks out frequently, please follow these steps in order to resolve the issue.

A. Make Sure Your OS is Up to Date:

- **Action:** Check for and install any available updates for macOS.
- **Steps:** Click on the Apple menu () in the top-left corner of your screen.
 1. Select **System Preferences** or **System Settings**, depending on your macOS version.
 2. Click on **Software Update**.
 3. If an update is available, follow the on-screen instructions to download and install it.
 4. **Reboot:** Restart your Mac after the update is complete to see if the issue persists.

B. Adjust Your Display Settings:

- **Action:** Modify display settings to prevent automatic adjustments that may cause flickering.
- **Steps:**
 1. Open **System Preferences** or **System Settings**.
 2. Go to **Displays**.
 3. Turn **off** the following options:
 - **Automatically adjust brightness**
 - **True Tone**
 4. **Reboot:** Restart your Mac to ensure the new settings take effect.

If these steps don't fix the issue, please file a helpdesk ticket with us:
<http://helpdesk.cad.rit.edu>