

Knowledgebase > Troubleshooting Guides > Troubleshooting an Apple laptop display that is flickering or frequently going black.

Troubleshooting an Apple laptop display that is flickering or frequently going black.

Erich S. Lehman - 2024-09-01 - Troubleshooting Guides

If you encounter a problem where your Apple laptop screen flickers or blacks out frequently, please follow these steps in order to resolve the issue.

A. Make Sure Your OS is Up to Date:

- Action: Check for and install any available updates for macOS.
- Steps: Click on the Apple menu ([]) in the top-left corner of your screen.
- 1. Select **System Preferences** or **System Settings**, depending on your macOS version.
- 2. Click on Software Update.
- 3. If an update is available, follow the on-screen instructions to download and install it.
- 4. Reboot: Restart your Mac after the update is complete to see if the issue persists.

B. Adjust Your Display Settings:

- Action: Modify display settings to prevent automatic adjustments that may cause flickering.
- · Steps:
- 1. Open System Preferences or System Settings.
- 2. Go to **Displays**.
- 3. Turn **off** the following options:
- Automatically adjust brightness
- **■** True Tone
- 4. Reboot: Restart your Mac to ensure the new settings take effect.

If these steps don't fix the issue, please file a helpdesk ticket with us: http://helpdesk.cad.rit.edu